

PRIMARY FLOW
(CH ZONE 1 & 2)

Hatched area shows recommended
1st fix pipework locations.

Dashed line shows recommended
minimum space requirement for
installation.

NOTE: Minimum distance from centre
line of unit to rear wall is 300mm.

Item	125l	145l	170l	210l	250l	300l
A	794	895	1020	1095	1323	1574
B	1102	1229	1384	1486	1738	2053
C	709	810	934	1011	1238	1526

DISCHARGE

EXPANSION VESSEL
CONNECTION

PRIMARY
RETURN

COLD INLET

FRONT